

SICO2 V2.7

General

The signal converter *SICO2* is a universal converter for voltage signals, digital (frequency) signals, logical signals (requires optional extension), signals from a serial port and signals from a *Controller Area Network* (CAN). The acquired signals can be assigned to any output of the *SICO2*. These are voltage signal outputs, digital signal outputs (e.g. frequency), logical signal outputs (requires optional extension), signals for a *CAN* and signals which are passed on to a host PC via a further serial port. Furthermore, up to eight signals can be displayed on the integrated LCD.

Before using the signal converter, it must first be set up. This is done by defining a parameter set with the PC program *TEMES* (Windows 95/NT4), and then by transferring this parameter set via a serial connection (COM1). *TEMES* also provides means to calibrate a voltage signal either at one known point (offset adjustment) or at two known points (two-point calibration). After everything is set up, the signal converter can do its job without necessarily being connected to the PC.




Figure 1: Signal converter SICO2.

Cycle Time / Sample Rate

The signal converter *SICO2* supports two task cycles. The duration of the first cycle (also called *sample rate*) is adjustable and lies within the range of 500 μ s to 15 s (in steps of 250 μ s). It is used for the voltage signal inputs, the frequency signal inputs and for frequency signal output. The second cycle, which is used for *CAN* signals, logical signals, digital signal outputs and calculated signals, runs at a rate of 100 Hz.

Voltage Signal Input

The signal converter can acquire up to eight voltage signals with a resolution of 10 bits. These signals must lie within the voltage range from 0 V to 5.12 V where 0 V correspond to bit value 0, and where 5.12 V correspond to bit value 1023. These raw signal values are always acquired with a sample rate of 250 μ s, and an average value over a period of the sample rate with a resolution of 16 bits is used to represent the value of the voltage signal (5.12 V correspond to bit value 65472). The internal impedance of each voltage input is greater than 10 M Ω . Voltage input signals can optionally be linearized via a table look-up with a refresh rate of 100 Hz. For this purpose user defined characteristic curves with up to 33 sampling points are used. Look-up values for input values, which lie between two sampling points, are obtained by linear interpolation.

Digital Signal Input

The signal converter has three channels for digital signals. If used as signal input, following signal types are supported:

Frequency Signal: The input voltage level (TTL, CMOS) may lie within the range from 0 V to 20 V. The resolution of each single measurement period is 108 ns. The frequencies to be measured may lie in the range from 0.1 Hz to 30 kHz. This range can accordingly be extended with an integrated integer prescaler from 1 to 65535. Note that the sum over all three prescaled input frequencies must not be greater than 30 kHz.

The digital signal can be triggered either with the raising or with the falling edge of the input signal, and is represented by the average value over a period of the sample rate.

Each digital input connector has a pin to supply a preamplifier (over a 220 Ω protective resistor) with the operating voltage of the data logger.

Switch State: Depending on the voltage level of the digital input, the digital signal is taken either as bit value 0 or as bit value 1. This signal type can be used for markers or to reset counter readings (see *calculated signals*).

Quadrature Signal: In this mode, the digital channel provides inputs for two voltage signals (e.g. from a *glass-scale* or an *incremental displacement transducer*) with a 90° phase difference. Depending on these two input signals (which may lie within the range from 0 V to 5 V), the current 16-bit-position value is either incremented or decremented (see

calculated signals to reset the current position value).

Pulse Width Measurement: The signal converter can detect the width of a pulse with a resolution of 108 ns. The largest detectable pulse width is 1.8 s with a resolution of 27.8 μ s.

Logical Signals: The state of all digital input signals (from all three digital channels) are available as a combined 6-bit-value. This value can be accessed like other logical input signals (via the I²C-bus for logical signals with a reserved internal bus address, see *logical input signals* for details).

Serial Ports

The signal converter has two serial ports. The first serial port is used for the communication between signal converter and host PC. The second serial port is used for (up to five) serial input signals, and thus it is connected to a GPS-receiver (*Garmin II*, using *NMEA* protocol) or a device, which supports the *F6*-protocoll (i.e. *SICO1*, *SICO2*, *DL16*, *DL16CAN*, *FU16uP*).

The signal converter distinguishes the two different signal sources by their baud rate. A baud rate of 4800 bps indicates the *NMEA*-protocol; all other baud rates are used with the *F6*-protocoll.

Logical Signal Input

The signal converter has three 16-bit input signals, which can be (in groups of 8 bits) fed into the signal converter over an I²C-bus with a refresh rate of 100 Hz. For each of the three 16-bit signals a bus address for the lower significant byte, and a bus address for the higher significant byte can be specified. External devices (which are connected to the signal converter) have bus addresses from 1 to 7.

To get further information about the current state of the signal converter the following bus address can be used:

Bus Address 256 (Internal 6-bit-logical-input):

bit 0	State of hardware pin <i>FRQ1 pin3</i>
bit 1	State of hardware pin <i>FRQ1 pin4</i>
bit 2	State of hardware pin <i>FRQ2 pin3</i>
bit 3	State of hardware pin <i>FRQ2 pin4</i>
bit 4	State of hardware pin <i>FRQ3 pin3</i>
bit 5	State of hardware pin <i>FRQ3 pin4</i>
bit 6	= 0 (reserved)
bit 7	= 0 (reserved)

Note that *pin4* of the corresponding digital channel is only accessible in operating mode *quadrature signal*.

Logical Signal Output

The signal converter cannot only acquire signals via the I²C-bus, it can also put out up to three 16-bit

signals (in groups of 8 bits). For each of the 16-bit signals a bus address for the lower significant byte, and a bus address for the higher significant byte can be specified. Bus addresses of external devices lie within the range from 1 to 7.

Multiple Purpose Channels

Standard Multiple Purpose Channels: Beneath the hardware signal sources like voltage input, digital input and serial input, the signal converter has 56 *standard multiple purpose channels*. Each of these channels is used to represent the value of either a CAN-signal or the result of a calculation.

Virtual Multiple Purpose Channels: Beneath the standard multiple purpose channels, the signal converter has further 44 *virtual multiple purpose channels*. These channels can be used like the standard ones with the restriction that there is only limited support to transfer their values online to the PC (only by polling each signal value instead of acquiring entire samples).

The assignment of multiple purpose channels is done automatically by *TEMES*.

CAN

The signal converter can be connected to a *CAN* (Controller Area Network). It has the ability to receive or transmit up to 14 *CAN messages* (with either 11-bit or 29-bit message identifiers). The messages (to be received or to be transmitted) are refreshed at a rate of 100 Hz.

Input signals are embedded within a received message. To extract them, following properties are supported: *start bit* within a message, *bit length* (max. 16 bits), *data type* (*unsigned* or *signed*) and *byte order* (*Intel* or *Motorola*).

Multiplex signals are only supported for message reception (and not for transmission).

The signal converter hardware (physical layer) is compatible to a *high speed CAN* (usually run at 125 kBit/s, 500 kBit/s or 1 MBit/s). An optional adapter is required to integrate the data logger in a *low speed CAN* (usually run at 83.3 kBit/s, 100 kBit/s or 125 kBit/s).

Note, that each of the two ends of a *high speed CAN* must be terminated (typically with a 120 Ω resistor between *CAN_H*-wire and *CAN_L*-wire).

Calculated Signals

The signal converter supports operations with signal values. For this purpose the signal values are treated as unsigned 16-bit integer values with little-endian (= Intel) byte order. Following operations are already built in the firmware: definition of constants; basic arithmetic (sum, difference, product, ratio); bit manipulations (AND, OR, XOR, mirror bits, byte order change from Intel to Motorola and vice versa);

comparisons ($=$, $<$, \leq); condition (use signal s_1 if condition is true, otherwise use signal s_2); delay (e.g. for derivation or signal filtering); counter operations (e.g. for 32-bit-counters or for integration). More complex operations can be obtained by using the result of a single operation as an operand for following operations.

Voltage Signal Output

The signal converter has four 12-bit-D/A-converters to put out up to four voltage signals with a refresh rate of the used sample rate. The output voltage lies within the range from 0 V to 5.12 V. Each output has an internal impedance of 510 Ω .

Digital Signal Output

Each of the three digital channels can also be used as signal output. The frequency of the output signal lies within the range from 0.3 Hz to greater than 100 kHz. Internally, four different frequency ranges with different frequency resolutions are distinguished and automatically selected by TEMES. The voltage level of the output signal lies within the range from 0 V to 5.12 V. Each output has an internal impedance of 510 Ω .

If a digital channel is used to put out a signal, it can only be used in operating mode *switch state* for input signals at the same time.

Display

The LCD (liquid-crystal display) has four lines with 20 alphanumeric characters per line. The LCD is considered as a 4×2 matrix with 8 cells and 10 characters per cell. Each cell shows one of the following display items: static text; signal value (either as fixed point value, hexadecimal value or binary value) or status information (like CPU load or sample rate).

A user-defined text can be displayed during the start-up of the signal converter (two lines). This can be used to display the name of the parameter set or the device number.

Sample Buffer

There are two supported ways to obtain the current signal values with a PC. The first method is asking for the current value of each signal by polling. The second (more sophistic) method is to define the signals of interest in advance. These signals are then permanently sampled by the signal converter with the user defined sample rate and buffered in a 1500-bytes queue (= sample buffer). The PC can then read from this queue to obtain not only the signal values but also a precise time stamp for each signal value.

Technical Data

Power supply:	6.5 V to 18 V DC
Current consumption:	about 85 mA
Sample rate:	from 500 μ s to 15 s in steps of 250 μ s
RS232-port:	4800 bps to 115.200 bps
CAN-Bit rate:	Up to 1 MBit/s; (1 MBit/s) / k , where k is an integer from 1 to 64
Box size without plugs, sockets, buttons and sliders:	90 × 70 × 24 mm

PC Software

The signal converter can be set up with the PC software TEMES. TEMES requires a PC with Windows 95/98/ME/NT4.0/2000/XP. The current version can be downloaded from the internet (<http://www.tellert.de>).

Further functions of TEMES are:

- **Online-Calibration:** The voltage input signals can be calibrated either at one known point (offset adjustment) or at two known points (two-point calibration).
- **Online-View:** The online-view displays a curve chart of the current signal values in the upper part of its window. The lower part of the window is used to display these values as numbers in physical units.
- **Exporting Measurements:** A measurement (see below for *Online-Recording*) can be exported to *ASCII*, *DIADEM*, *TurboLab* or *x-y Recorder* format. TEMES provides a documented DLL interface for accessing TEMES measurement files. This allows programmers to read TEMES measurement files without knowing the internal file structure.

Following TEMES functions require an optional available single-PC license:

- **Online-Recording:** The current signal values which are displayed in the online-view can be saved to a PC file.
- **Import of ASCII files:** Measurements can be imported from ASCII files.

Additional Properties

The signal converter has further properties, which are not already supported by the recent program version of TEMES.

User defined functions: It is possible to integrate self-written assembler routines within the sample-rate-loop or 10-ms-loop of the signal converter. User defined functions can be provisionally implemented with TEMES V1.0 by embedding the hex dump of

the corresponding binary file within the device comment of a TEMES parameter set.

Assignment of regions: The signal converter has an operation, which divides the 16-bit-number-space into ranges. The result of this operation is the range number, which belongs to the input signal.

Variable text output: The signal converter has the ability to select one item of a string list (by using the signal value as list index) and to display that string.

Scope of supply

The delivery of a signal converter *SICO2* includes:

- *SICO2* box
- 4-pin-cable for power supply (12 V DC) and CAN with open wire ends
- PC-connection cable with 9-pin SUB-D-socket
- PC-software (TEMES)
(requires Windows 95/98/ME/NT4.0/2000/XP)

Optional Accessories

General accessories:

- Power transformer (Euro plug; 100-230 V AC; 50-60 Hz)
- Accu-pack (with rechargeable Ni-MH battery cells) *AC230*, *AC230/12* and *AC230/24*
- Low speed CAN adapter *LCC719* (to connect the *SICO2* to a low speed CAN)

Accessories for digital input:

- Hall effect sensor *HS-M10X1* (to detect passing magnets)
- Hall effect sensor *FPS* (to measure the frequency of steal teeth wheels, even at lowest frequencies; requires preamplifier *FP1*)
- Preamplifier *FP1* for hall effect sensor *FPS*
- Preamplifier *PP3* for AC-coupled signals (for magnetic sensors)

Accessories for voltage input:

- Passive voltage transformer *BNC-PI2* or *RVT2*
- Galvanically isolated preamplifier *INA1*
- Acceleration sensor *DAC50*
- NTC temperature sensor *NTC10K* (operating point 25 °C) and *NTC2K* (operating point 66 °C) for temperatures from -40 °C to 150 °C
- Thermal sensor amplifier *TH2*
- DC-bridge amplifier *DCBA2/DCBA8*
- Barometric height meter *HM2*

Accessories for logical signals:

- Switch/button *SW1* for *SICO2* digital input
- Input for eight logical signals *LI8*
- Output for eight logical signals *LO8*

Version History

Signal Converter *SICO2 V2.2*: First release of the signal converter *SICO2 Version 2* series.

Signal Converter *SICO2 V2.2 R5*: Support for pulse width measurement (digital input signal).

Signal Converter *SICO2 V2.7*: Expanded with an I²C-bus connector for logical signals (input/output).

Pin Assignment

The sockets and plugs of the signal converter are manufactured by *Binder* and parts of *Binder Series 719*. The socket pins (in front view) are numbered clockwise starting with the first pin after 12 o'clock position. The plug pins are numbered correspondingly anti-clockwise. The first pin is respectively labeled at the solder side (back view).

POWER/CAN: This plug supplies the signal converter with voltage and connects the logger to a CAN.

Pin	Assignment [Cable Color]
1	Supplying voltage (7 V to 20 V DC inverse-polarity protected) [red]
2	Ground [brown]
3	CAN_L [black]
4	CAN_H [orange]

RS1/2: This plug provides two serial ports. Note, that the data logger is either shipped with option *GPS* (standard) or option *RS232* (on request).

Pin	Assignment	SUB-D-Plug of host PCs [Comment]
1	TX1	Pin 2
2	Ground	Pin 5
3	RX1	Pin 3
4	U _B – 1 V	Option <i>GPS</i>
	TX2	Option <i>RS232</i> [Serial data output]
5	RX2	[Serial data input, i.e. GPS]
		Pins 7 and 8 are bridged
		Pins 1, 4, 6 are 9 bridged

AN1/2: This socket provides inputs for the *voltage input signals* 1 and 2.

Pin	Assignment
1	Supplying voltage – 1 V
2	Ground
3	Analog input 1
4	Analog input 2
5	5.12 V Reference voltage (max. 20 mA for AN1-AN8)

AN3/4: This socket provides inputs for the *voltage input signals* 3 and 4.

Pin	Assignment
1	Supplying voltage – 1 V
2	Ground
3	Analog input 3
4	Analog input 4
5	5.12 V Reference voltage (max. 20 mA for AN1-AN8)

AN5/6: This socket provides inputs for the *voltage input signals* 5 and 6.

Pin	Assignment
1	Supplying voltage – 1 V
2	Ground
3	Analog input 5
4	Analog input 6
5	5.12 V Reference voltage (max. 20 mA for AN1-AN8)

AN7/8: This socket provides inputs for the *voltage input signals* 7 and 9.

Pin	Assignment
1	Supplying voltage – 1 V
2	Ground
3	Analog input 7
4	Analog input 8
5	5.12 V Reference voltage (max. 20 mA for AN1-AN8)

FRQ1: This socket provides a connection to the first digital (frequency) signal.

Pin	Assignment
1	Supplying Voltage – 1 V ($R_i = 220 \Omega$)
2	Ground
3	Digital input 1 (connected over 100 k Ω to 5 V)
4	Frequency output or second input for quadrature signal

FRQ2: This socket provides a connection to the second digital (frequency) signal.

Pin	Assignment
1	Supplying Voltage – 1 V ($R_i = 220 \Omega$)
2	Ground
3	Digital input 2 (connected over 100 k Ω to 5 V)
4	Frequency output or second input for quadrature signal

FRQ3: This socket provides a connection to the third digital (frequency) signal.

Pin	Assignment
1	Supplying Voltage – 1 V ($R_i = 220 \Omega$)
2	Ground
3	Digital input 3 (connected over 100 k Ω to 5 V)
4	Frequency output or second input for quadrature signal

AOUT: This socket provides outputs for four voltage signals.

Pin	Assignment
1	Analog output 1 (0 V to 5.12 V; $R_i = 510 \Omega$)
2	Analog output 2 (0 V to 5.12 V; $R_i = 510 \Omega$)
3	Analog output 3 (0 V to 5.12 V; $R_i = 510 \Omega$)
4	Analog output 4 (0 V to 5.12 V; $R_i = 510 \Omega$)
5	Ground

LOGIC I/O: This socket provides access to an I²C-bus for logical input and output signals.

Pin	Assignment
1	Supplying voltage – 1 V
2	Ground
3	SDA (serial data line)
4	SCL (serial clock line)

SICO2B

The display of signal converter *SICO2B* is larger than that of *SICO2*. Furthermore, it is disengageable backlit.

The pin assignment of *SICO2B* is the same as that of *SICO2*.




Figure 2: Signal converter *SICO2B*.

Box size (without plugs, sockets, buttons and sliders):

115 mm × 70 mm × 30 mm

SICO2I

The signal converter *SICO2I* has the same display as the signal converter *SICO2B*. The voltage outputs and digital channels are implemented as *bayonet nut connector* (BNC) sockets. The direction of the digital channels is set either to input or output via sliders. The voltage signal inputs are fed in via a SUB-D-socket. The connectors for POWER/CAN and RS232 are from Binder Series 711 and Binder Series 712 (Pin assignment is identical to that of *SICO2*).

SICO2I does not support quadrature signals (unlike *SICO2* or *SICO2B*).



Figure 3: Signal converter *SICO2I* (Connectors).



Figure 4: Signal converter *SICO2I*.

SUB-D-socket (Type HD15) pin assignment:

Pin	Assignment
1	Analog input 1
2	Analog input 2
3	Analog input 3
4	Analog input 4
5	Analog input 5
6	Analog input 6
7	Analog input 7
8	Analog input 8
9	
10	Ground
11	Supplying voltage – 1 V
12	5.12 V Reference voltage (max. 20 mA for AN1-AN8)

Box size (without plugs, sockets, buttons and sliders):

120 mm × 118 mm × 42 mm

SICO2BI

The signal converter *SICO2BI* is an extended version of *SICO2I*. Instead of the SUB-D-socket, the voltage signal input connectors are the same as the connectors of SICO2 (Binder Series 719). Optionally, preamplifiers for the analog input signals (e.g. *TH2* or *DCBA2*) can be integrated within the case of the *SICO2BI*. These preamplifiers can be bypassed with sliders (where each slider controls the bypass for two adjacent voltage input signals).

Additionally to SICO2I, the digital channels are also connectable via sockets of type Binder Series 719 (same as *SICO2*).

Box size (without plugs, sockets, buttons and sliders):

120 mm × 118 mm × 56 mm